



Collection Pools

HM1048AB, HM1048SB Standard Collection Pool


HM1044AB, HM1044SB Compact Collection Pool



1. Open Velcro wrap around pool handles so pool frame may be unfolded.




2. Place collection pool on a hard and level surface. A tarp may be used over rough ground to protect the pool liner.



3. Extend each side of pool until hinge locks. Secure non-hinged side of pool with one locking pin. (Standard Collection Pool only).

CAUTION: Use care when opening the pool. Pinch points may occur at hinges.



4. Pool is ready for use.

Operation

- A. Inspect pool liner for holes, tears, or evidence of chemical breakdown prior to use.
- B. Place collection pool on top of a ground tarp and dike area surrounding the pool when working with hazardous materials.

Storage

- A. Remove locking pin.
- B. Collapse pool by bending each side at the hinge.
- C. Secure with strap.

Maintenance

- A. Lubricate hinges as needed.
- B. Inspect pool liner after each use for tears, holes, or evidence of chemical breakdown. If present, replace pool liner before use or storage. (Use Standard Pool Replacement Liner (HM1050) or Compact Collection Pool Replacement Liner (HM1051)).
- C. Store in a warm and dry area. Avoid dropping and striking against hard objects.

Reuse

- A. Determine compatibility of chemical with liner of collection pool.
- B. Inspect tarp for holes, tears, discoloration, or evidence of chemical breakdown.
- C. Test integrity of collection pool by filling with water and checking for leaks prior to use. If there is any doubt, replace liner.